

MIPS-Fusion: Multi-Implicit-Submaps for Scalable and Robust Online Neural RGB-D Reconstruction

Supplemental Material

Yijie Tang*, Jiazhao Zhang*, Zhinan Yu, He Wang, Kai Xu[†]



National University of Defense Technology



Peking University

* Joint first authors

† Corresponding author: Kai Xu (kevin.kai.xu@gmail.com)

Outline

- 1. Metrics of reconstruction quality
- 2. Downsampling algorithm
- 3. Quantitative evaluation on TUM dataset
- 4. Quantitative evaluation on FastCaMo-Synth
- 5. Quantitative evaluation on Replica
- 6. Evaluation on rendering quality
- 7. Visual comparison on Scannet, FastCaMo
- 8. Visual results of FastCaMo-Large

Metrics of reconstruction quality: Accuracy details

- Accuracy Acc is the indicator that describes the difference between two point cloud S and G , it is formulated as below:

$$Acc = \frac{1}{\sum A(s)} \sum_{s \in S} A(s) \min_{g \in G} \|s - g\|_2,$$

where $A(s)$ represents the area around vertex s .

Metrics of reconstruction quality: Completeness details

- Completeness $Compl$ is the indicator that describes the percentage of inlier vertexes between two point cloud S and G , it is formulated as below:



$$Compl = \frac{100}{\sum A(g)} \sum_{g \in G} A(g) \min_{s \in S} \|s - g\|_2^0,$$

where $\|s - g\|_2^0$ is defined via parameter ε as:


$$\|s - g\|_2^0 = \begin{cases} 0, & \text{if } \|s - g\|_2 < \varepsilon \\ 1, & \text{otherwise} \end{cases}$$

Down-sample Depth Map

We down-sample the depth map with a specific offset which vary along with the iteration.



Down-sample $\times 4$
offset 0



Down-sample $\times 4$
offset 1

Quantitative evaluation on FastCaMo-Synth dataset

	ElasticFusion	BundleFusion	MIPSFusion
Apartment_1	40.9cm	4.6cm	6.6
Apartment_2	40.7cm	2.2cm	3.1cm
Frl_apartment_2	43.8cm	83.6cm	2.6cm
Office_0	22.3cm	2.7cm	5.2cm
Office_1	2.3cm	17.3cm	7.6cm
Office_2	65.9cm	93.0cm	17.4cm
Office_3	94.3cm	253.5cm	24.9cm
Hotel_0	43.8cm	65.2cm	6.0cm
Room_0	-	-	4.47cm
Room_1	31.0cm	0.6cm	3.65cm

(ATE)

Results on FastCaMo-Synth (noise)

Quantitative evaluation on Replica

		office_0	office_1	office_2	office_3	office_4	room_0	room_1	room_2	avg
NICE-SLAM	accuracy(cm)⬇️	2.939	2.679	3.476	3.359	2.715	2.767	2.455	2.180	2.821
	completion(cm)⬇️	1.879	1.862	3.059	3.187	3.646	2.635	2.213	2.756	2.655
	comp ratio(%)⬆️	95.02	93.97	88.49	86.99	87.05	91.87	93.47	91.36	91.03
Vox-Fusion	accuracy(cm)⬇️	1.730	2.993	2.231	2.866	3.320	2.407	1.615	3.141	2.374
	completion(cm)⬇️	1.396	1.584	2.692	2.667	2.880	2.624	2.206	1.945	2.227
	comp ratio(%)⬆️	97.14	95.73	91.12	90.85	89.53	92.73	93.51	94.18	92.84
Ours	accuracy(cm)⬇️	3.211	2.827	4.138	3.278	3.316	3.084	3.083	2.559	3.187
	completion(cm)⬇️	3.099	4.215	3.595	3.125	2.921	2.015	2.003	3.250	3.028
	comp ratio(%)⬆️	90.68	84.94	84.84	88.90	91.31	96.95	95.49	89.17	90.29

Evaluation on rendering quality

ScanNet

	PSNR	MSE	SSIM
NICE-SLAM	26.6	0.0022	0.9717
MIPSFusion	25.4	0.0029	0.9647

FastCaMo-Large


	PSNR	MSE	SSIM
NICE-SLAM	15.2	0.0298	0.6139
MIPSFusion	23.0	0.0049	0.9118

FastCaMo-Synth


	PSNR	MSE	SSIM
NICE-SLAM	13.3	0.0464	0.7855
MIPSFusion	27.2	0.0019	0.9521

Average results of NICE-SLAM and our method on FastCaMo-Synth and ScanNet


Evaluation on rendering quality



Evaluation on w./w.o. non-trivial loop



One round



Second round

Visual comparison on Scannet, FastCaMo-Real




NICE-SLAM

Vox-Fusion



MIPS-Fusion

Ground Truth

Apartment-I



Lab




Visual comparison on Scannet, FastCaMo-Real

NICE-SLAM Vox-Fusion MIPS-Fusion Ground Truth
Lounge-i




Scene0011




Visual comparison on Scannet, FastCaMo-Real

Scene0207




Visual results of FastCaMo-Large




Lab ($\sim 60\text{m}^2$)

Visual results of FastCaMo-Large




Classroom ($\sim 80\text{m}^2$)

Visual results of FastCaMo-Large




Floors-I ($\sim 230 \text{ m}^2$)

Visual results of FastCaMo-Large




Floors-II ($\sim 250 \text{ m}^2$)

Visual results of FastCaMo-Large



Stairs-I ($\sim 100 \text{ m}^2$)

Visual results of FastCaMo-Large



Stairs-II ($\sim 90 \text{ m}^2$)